



bubble lamp

Bubble lamp is a hand-made organic wall lamp, fired in bisqueware. The light has a pull-switch.

MATERIAL SIZE COLOR BULB VOLTAGE	Ceramic Bisque 11x6x5 inch White / Beige GX53 110-240V	*All pieces are h each piece uniq shape, texture, o occur due to its natural ma process.

All pieces are handmade, making ach piece unique. Inconsistency in nape, texture, color and size may ccur due its natural material and working occess.





installation:

01_ Mount the socket to the wall using the screws provided.

02_ Drill the whole in the wall above the socket.


03_Insert the bulb.

04_Insert wall plug into the hole, ensuring it is flush with the wall. Next, insert a screw with brass cap into the wall plug, leaving around 1 inch of the screw tip exposed (the whole cap).

04_Carefully hang the wall lamp on the exposed screw cap, ensuring it is securely in place.

safety note:

All works must be under electricity disconnected, all opeartion under the national valid regulations. Observance instuctions manual is parts of guaranty, wrong opeation without observance instuctions manual may lead to equipment damaged, fire or other danger.





bubble lamp 02

Bubble lamp is a hand-made organic wall lamp, fired in bisqueware. The light has a pull-switch.

MATERIAL	Ceramic Bisque
SIZE	11x6x5 inch
COLOR	White / Beige
BULB	GX53
VOLTAGE	110-240V

*All pieces are handmade, making each piece unique. Inconsistency in shape, texture, color and size may occur due to its natural material and working process.





installation:

01_ Mount the socket to the wall using the screws provided.

02_ Drill the whole in the wall above the socket.

03_Insert the bulb.

04_Insert wall plug into the hole, ensuring it is flush with the wall. Next, insert a hook into the wall plug, leaving around 1 inch of the screw tip exposed.

04_Carefully hang the wall lamp on the exposed hook, ensuring it is securely in place.

safety note:

All works must be under electricity disconnected, all opeartion under the national valid regulations. Observance instuctions manual is parts of guaranty, wrong opeation without observance instuctions manual may lead to equipment damaged, fire or other danger.